For service, contact the store where you purchased the device.

Instructions for use

Gabbiano hanging dryer 1600A



Rev. A/09/2025

Construction:



Caution!

1. Use of the device by children and persons with reduced physical, sensory or intellectual abilities, as well as those without knowledge or experience in the use of such devices
   use of this type of equipment is possible provided that they are closely supervised and trained in the safe use and potential dangers
   arising from its use.

2. The device and the power cord should be inspected regularly to rule out defects and damage. If the device shows signs of damage, stop using it immediately, turn off the power supply and have it repaired by an authorized service technician.
3. The device must not be immersed in water or wet cleaned.
4. The air outlet grille heats up during the operation of the dryer, this condition is determined by its operation. Touching the grille may result in burns.
5. It is forbidden to interfere with the design of the device to change its parameters or construction.
6. Cleaning and maintenance must not be performed by children without adult supervision.
7. It is recommended to unplug the power supply when the product is not in use.
8. Make sure the dryer stands on a stable, level surface.
9. Avoid contact of the dryer with water.
10. Use the device only in dry and well-ventilated areas.
11. Unplug the appliance from the power supply before cleaning, maintaining or moving it.
12. Make sure the device is stably mounted before starting work.
13. To prolong the life of the unit, when you have finished working, set the temperature control knob to the cooling position and leave it in this position for at least one minute before turning off the power.

Technical data:

- Stainless steel heating elements
- Temperature control from 40 to 75°C
- Time adjustment from 0-60 min
- Power 950W

Problems and solutions:

Problem	Action	Solution
Problem with heating Device and fan movement	Check that the cable is properly connected to the outlet	Disconnect and reconnect the cable to the outlet.
	Make sure you have turned on the heating and timer	Turn on the heating and timer
	Check the fuse	Replace the fuse
Device Blows only cool air	Check temperature control switch	Set temperature control switch to heat up
	Check the wiring of the heating element	Connect the wire to the heating element
	Check heating element	Replace heating element
Poor heating with no blowing	Check motor and capacitor wiring	Connect the leads of the motors and capacitors
	Check the motor	Replace the engine

SAFETY MEASURES

1. The device is a professional equipment for use in beauty parlors. Operation of the device only by qualified cosmetic personnel avoids undesirable consequences during treatment.

2. Do not disassemble the device or attempt to use it for purposes other than those indicated in this manual. All servicing and repairs must be performed only by an authorized service technician.

3. Do not install or operate the device near liquids, wet places or with wet hands - so that no liquids get into the device.

4. Immediately remove the plug from the outlet and contact the authorized service in the following cases: a) liquid has gotten into the device, b) the device emits a strange smell, smoke or makes strange sounds, c) the power cord has been damaged, d) the device has been knocked over or its housing has been damaged.

5. Do not lay any objects on the cables. Do not install the device where someone may step on the power cord.

6. For safety purposes, unplug the power cord from the outlet each time you finish working with the device.

7. Do not insert anything into the opening of the device. If a foreign object gets into the hole, remove the cord from the outlet and contact the distributor or manufacturer.

8. Do not place the device on an unstable cart, shelf or vehicle. If dropped, the device may be damaged.

9. In order to guarantee the established useful life of the device, it is recommended to keep an interval of one minute before pressing the power button again (between switching on and off and vice versa).

10. The power supply must comply with the specifications on the nameplate. Otherwise, there is a risk of incorrect operation of the device its damage and even burning.

CAUTION:

1. In case of damage to the power cord or other malfunctions, contact an authorized service center - this will avoid danger.

2. This equipment may be used by children at least 8 years of age and by persons of diminished physical and mental capabilities and persons with inexperience and lack of familiarity with the equipment, if supervision or instruction on how to use the equipment in a safe manner is provided so that the associated risks are understood.

3. The equipment is not intended for play by children. Do not allow children to play with the equipment.

4. Do not leave the appliance unattended when children or persons without sufficient knowledge of the use of the appliance are in the vicinity.

5. This electrical appliance is not a toy. Improper use or contact with the electrical appliance may pose a health risk or lead to death, so use and store the appliance out of the reach of children.



DISPOSAL OF THE DEVICE

Dispose of used electrical appliances, fixtures and packaging to raw material reprocessing centers in accordance with environmental protection principles. Electrical appliances should not be disposed of in household waste containers. Follow the rules for discarding this type of equipment. In order to protect the environment in accordance with Directive 2012/19/EC concerning waste electrical and electronic equipment
Waste electrical and electronic equipment should be collected separately, and then handed over to collection points for waste electronic and electrical equipment.

At the end of their useful life, and old appliances contain full-value recyclable components, so they should be handed over for reprocessing. Therefore, they should be handed over to appropriate collection points.

STORAGE AND TRANSPORT

The device should be transported at a temperature in the range of (-) 20 °C to (+) 50 °C only in its original packaging. Store the device in a well-ventilated and relative humidity of no more than 75%. Operating temperature from (+) 10 °C to (+) 40 °C. During storage and transportation processes, the device must not be thrown or dropped, exposed to mechanical shocks or atmospheric agents.