For service, contact the store where you
purchased the device.

INSTRUCTIONS FOR USE

ACDS-100 ultrasonic cleaner




Rev. A/04/2024

Technical data:

Voltage	220 - 240 V 50Hz
Power	50 W
Vibration frequency	42 kHz
Dimensions	20.4 x 14.0 x 13.0 cm
Dimensions of tank	16.1 x 8.5 x 5.0 cm
Tank capacity	600 ml
Minimum liquid level	50 ml
Maximum fluid level	500 ml
Weight	0.98 kg
Timer	90 - 600 s

- Unplug the unit before filling the tank. Do not exceed the "MAX" line to avoid overfilling.
- Do not fill the tank with abrasive or corrosive chemicals. This may cause leakage, resulting in damage.
- Do not use the washer if the cord or plug is damaged. If damaged, contact a service center for inspection and repair.
- Store the washer in a safe, dry and non-sunny place
- The washer should never be left unattended while plugged in.
- Do not use while bathing.
- Disconnect the washer from the power source after use.
- Do not immerse the washer in water to avoid electric shock
- The water should be poured through the place on the washer indicated by the arrow.

Washer construction and accessories:



1. Lid
2. Maximum liquid level line
3. Tank
4. On/off switch
5. Time display
6. Time setting key
7. Power cord socket
8. Basket
9. Watch stand (optional)
10. Power cable

STORAGE AND HANDLING



1. Do not turn on the washer without water inside. Turning on the washer without water may damage the washer.
2. Do not overload the washer with continuous operation. After 30 minutes of continuous operation, leave the washer idle for another 10 minutes.
3. Do not leave water in the washer permanently. Pour the water or solution out of the washer after use. Leaving water or solution in the washer for a long time can damage it.
4. Take care of the outside of the washer. Wipe off any residual water or solution immediately. Use a damp towel to clean the washer. Wipe dry after washing.

INSTRUCTIONS FOR USE

1. Remove the lid. Put the products into the basket and then into the tank of the washer.
   For sharp objects that can damage the washer, be sure to use the basket. Also remember that the basket absorbs 3040% of the ultrasonic energy of the washer.

2. Fill the tank with water. The water must cover the objects to be cleaned, but must not exceed the maximum liquid level.

3. Put the lid on, and then connect the washer to the power supply.
   The display will show 180. This is the default time for washing with the washer.


4. Set the selected time with the time setting key.
   Possible choice 180s, 300s, 480s, 600s 90s.

5. Turn on the washer with the switch. The cleaning process will start. The time will count down to 0.

6. When zero appears on the display, the washer will automatically stop.

7. If you want to finish cleaning before time time, press the switch. If you need to repeat the cycle or increase the cleaning time, press the button
   set time, select the appropriate time and press the switch to restart the machine.
8. When you're done, unplug the device, pour out the remaining water and wipe the device dry.

9. Store in a dry and cool place.



CLEANING METHODS





1. Ordinary washing.

Use water according to the instructions for use. Pour out the water after use

2. Washing in solution

Prepare the cleaning solution according to the manufacturer's recommendations. Be careful not to exceed the concentration of the solution. Doing so may damage the seals in the washer, resulting in a risks flooding electronic components. When you are finished, fill the washer with water, turn it on for 90 seconds, and then pour the residue out of the washer. This will prevent damage to the washer from prolonged contact with chemicals.

INSTRUCTIONS FOR USING OPTIONAL ACCESSORIES



Basket - use the basket to clean small and delicate items. When cleaning several items, make sure the items do not come into contact with each other.



Watch stand - use the stand to keep the watch above the surface of the water when cleaning the bracelet.

ITEMS NOT SUITABLE FOR WASHING IN AN ULTRASONIC CLEANER

- Delicate jewelry (pearls, emerald, ivory items, beads, seashells, agate).
- Welded, coated and glued items
- Other items such as wood, coated glass, ceramic products, camera filters.

SAFETY MEASURES

1. The device is a professional equipment for use in beauty parlors. Operation of the device only by qualified cosmetology personnel avoids undesirable consequences during treatment.
2. Do not disassemble the device or attempt to use it for purposes other than those indicated in this manual. All servicing and repairs must be performed only by an authorized service technician.
3. Do not install or operate the device near liquids, wet places or with wet hands - so that no liquids get into the device.
4. Immediately unplug the device from the outlet and contact the authorized service in the following cases: (a) liquid has gotten into the device, (b) the device emits a strange odor, smoke or makes strange sounds, (c) the power cord has been damaged, (d) the device has been knocked over or its housing has been damaged.

5. Do not lay any objects on the cables. Do not install the device where someone may step on the power cord.
6. For safety purposes, unplug the power cord from the outlet each time you finish working with the device.
7. Do not insert anything into the opening of the device. If a foreign object gets into the hole, remove the cord from the outlet and contact the distributor or manufacturer.
8. Do not place the device on an unstable cart, shelf or vehicle. If dropped, the device may be damaged.
9. In order to guarantee the established useful life of the device, it is recommended to keep an interval of one minute before pressing the power button again (between switching on and off and vice versa).
10. The power supply must comply with the specifications on the nameplate. Otherwise, there is a risk of incorrect operation of the device its damage and even burning.

CAUTION:

1. In case of damage to the power cord or other malfunctions, contact an authorized service center - this will avoid danger.
2. This appliance can be used by children at least 8 years of age and by persons with reduced physical and mental capabilities and persons with inexperience and lack of familiarity with the equipment, if supervision or instruction on the use of the equipment in a safe manner is provided, so that the associated risks are understood.
3. The device is not intended for play by children. Do not allow children to play with the device.
4. Do not leave the appliance unattended when children or persons without sufficient knowledge in the use of the appliance are near it.
5. This electrical appliance is not a toy. Improper use or contact with the electrical appliance may pose a health risk or lead to death, so use and store the appliance out of the reach of children.

DISPOSAL OF THE DEVICE

Dispose of used electrical appliances, fixtures and packaging to raw material reprocessing centers in accordance with environmental protection principles. Do not dispose of electrical appliances in household waste containers. Follow the rules for discarding this type of equipment. In order to protect the environment in accordance with Directive 2012/19/EC on waste electrical and electronic equipment, waste electrical equipment should be collected separately, and then handed over to collection points for collection of used equipment. Electronic and electrical. At the end of their useful life, as well as old devices contain full-value recyclable components, so they should be handed over for reprocessing. Therefore, they should be handed over to appropriate collection points.

STORAGE AND TRANSPORT

The device should be transported at temperatures between (-) 20 °C and (+) 50 °C only in its original packaging. Store the device in a well-ventilated area with a relative humidity of no more than 75%. Operating temperature from (+) 10 °C to (+) 40 °C. During storage and transportation processes, the device must not be thrown or dropped, exposed to mechanical shocks or atmospheric agents.